
- Lightweight aggregate blocks
 - Wet plaster



DO

- Keep cavity and wall ties free from mortar droppings and debris
- Fully fill all blockwork joints with mortar
- Make sure there is no connection between the two leaves except for wall ties and foundation
- Keep any chases for services to a minimum and fill well with mortar
- Select an alternative robust detail where flues are required in the separating wall e.g. for lightweight aggregate blocks, see E-WM-4
- Refer to Appendix A